

INSTALLATION NOTE

Mini Mimic Escutcheon Plate

Feature Overview:

The Mini Mimic Escutcheon Plate allows the F100A LCD Mini Mimic to be flush-mounted in the wall cavity.

Dimensions:

Outer 260mm x 157mm x 1mm (W x H x D)

Inner 200mm x 97mm (W x H)

Mounting:

1. Remove the four countersunk machine screws on the top and bottom of F100A LCD Mini Mimic, and remove the Mini Mimic cover plate. Place the cover face-down on a scrap surface.
2. From the inside, drill out the four holes for the machine screws through the label.
3. Locate the existing dwang inside the chosen wall location, or be prepared to add a horizontal support member inside the wall.
4. Cut the correct-sized hole in the wall board. Add or locate a suitable rear mounting surface for the Mini Mimic.
5. Secure the Mini Mimic—there are two mounting holes suitable for screw head mounting.
6. Replace the four machine screws, through the Escutcheon Plate, into the original holes of the Mini Mimic as shown in the diagram below.

