Warranty

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details.

Electronic warranty form at www.sti-usa.com/wc14.

A WARNING: This product can expose you to chemicals including Dichloromethane, which is known to the State of California to cause cancer, and Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm.

For more information go to www.P65Warnings.ca.gov.



Stopper II® Heated Enclosure

STI-1200A-HTR STI-1200A-HTR240



- Maintains initiating device temperature with external temperatures to -70°F . (-57°C). Independently tested to -102°F (-73°C).
- Protects initiating devices for addressable units to UL 38 Standards.
- The clear, protective polycarbonate cover is UV-stabilized against discoloration. .
- Enclosure rated to NEMA 3R Standards to provide a degree of protection against rain, sleet, and damage from external ice formation.
- Fan runs continuously to maintain a uniform temperature inside the enclosure. .
- Heater units cycle as required to maintain the correct range of operating temperatures.
- Three year guarantee against breakage of polycarbonate in normal use (one • vear on electro mechanical and electronic components).
- UL/ULC Listing does not require standby or secondary power for 110 or 240 VAC 50/60 Hz heater.



International

2306 Airport Rd · Waterford, MI 48327, USA Phone: 248-673-9898 • Fax: 248-673-1246 info@sti-usa.com • www.sti-usa.com

Safety Technology International Ltd

Taylor House • 34 Sherwood Road • Bromsgrove Worcestershire • B60 3DR • England • Tel: +44 (0)1527 520 999 Fax: +44 (0)1527 501 999 · info@sti-emea.com · www.sti-emea.com

Subject to change without notice. Printed in USA

Warnings and Installation Notes

The enclosure is used to protect UL Listed 38 and 2017 initiating devices at temperatures down to -70°F (-57°C). It is the installer's responsibility to comply with NEC 70 Articles 725 and 760, NFPA 72, and other applicable fire and electrical codes. Conduit or raceway paths need to be sealed as near to the enclosure as possible. Installer should have maintained supervision over the low temperature thermostat. The low temperature monitoring thermostat makes the circuit at +32°F (0°C) and clears the circuit at +50°F (+10°C). This listing requires that the fire alarm supervisory control module be only of the latching type. On the appliance mounting plate is a label where you should record the installation date. Also include below the serial number and installation date on the instruction sheet for quick reference.

Serial Number_____ Installation Date_____

NOTE: Operating voltage for the STI-1200A-HTR is 110 VAC. Operating voltage for the STI-1200A-HTR240 is 240 VAC.

- 1. Use of an outdoor rated initiating station is required with this heated enclosure.
- When conducting periodic testing, if conditions are dusty or if you have wind blown dust conditions, cover return grill ports to minimize entrance of dust or sand particles. To remove accumulated dust or sand particles, use small containers of compressed air that is used for electronic cleaning.
- 3. To reset the thermal circuit breaker push button.
- If circuit breaker will not remain in a restored or closed position, conduct an electrical check of the various components in the two voltage classes. The two voltage classes are 24 VDC Negative Ground and 110 or 240 VAC 50-60 Hz with connected electrical or earth ground. High voltage (110 or 240 VAC) wiring must enter through bottom conduit. Low voltage and signaling wires must enter through top conduit and remain separated per NFPA 70, NEC, and local codes.
- 4. If the thermal circuit breaker has tripped (opened circuit), the 110 or 240 VAC 50-60 Hz power will still be energized up to the primary side of the thermal breaker. For safety, disconnect supply power of conductors to three power circuits in the enclosure.
- To clean 24 VDC negative ground fan with electronic compressed air container, disconnect all power. Note: the 24 VDC negative ground fan will not operate if positive and negative conductors are connected on the wrong terminals.
- 6. To minimize arid summer time heat build up in enclosure, install a dark color sun shield with sides to provide shade for the enclosure. At the inclined face above the enclosure at the point of contact with the building structure leave at least 1/2" or (1.25 cm) space. This will generate heat and cause an upward airflow and help maintain the enclosure temperature approximately the same as ambient air temperature.
- 7. The 110 or 240 VAC single phase 50-60 Hz heater does not require standby or secondary power because the enclosure environment is supervised by a latching supervisory circuit in the alarm control unit or panel.
- Replacement of heater assembly and gasket is required five years from installation date. Contact STI to order replacement Heater Kit STI-HK3.
- 9. All field wiring within this enclosure must be rated for a minimum operating range of 0°C 110°C.

Mises en garde et remarques sur l'installation

Le boîtier est utilisé pour protéger les dispositifs de déclenchement homologués UL 38 et 2017 à des températures allant jusqu'à -70 °F (-57 °C). Il incombe à l'installateur de se conformer aux articles 725 et 760 de la NEC 70, NFPA 72, et aux autres codes de prévention des incendies et de l'électricité en vigueur. Les chemins des conduites ou canalisations doivent être soclés aussi proche que possible du boîter. Il est attendu que l'installateur ait effectivement contrôlé le thermostat à basse température. Le contrôlé du thermostat à basse température maintient le circuit à 32 °F (0 °C) et déclenche le circuit à 50 °F (10 °C). Cette homologation exige nécessite que le module de contrôlé de la surveillance des alertes d'incendie soit uniquement du type à verrouillage. La plaque de montage de l'appareil comporte une étiquette sur laquelle vous devez enregistrer sa date d'installation. Le numéro de série et la date d'installation doivent aussi être marqués sur la feuille d'instruction pour référence rapide.

Numéro de série _____ Date d'installation


REMARQUE: La tension de service du STI-1200A-HTR est de 110 VCA. La tension de service du STI-1200A-HTR240 est de 240 VCA.


- 1. Use of an outdoor rated initiating station is required with this heated enclosure.
- When conducting periodic testing, if conditions are dusty or if you have wind blown dust conditions, cover return grill ports to minimize entrance of dust or sand particles. To remove accumulated dust or sand particles, use small containers of compressed air that is used for electronic cleaning.
- 3. To reset the thermal circuit breaker push button.

If circuit breaker will not remain in a restored or closed position, conduct an electrical check of the various components in the two voltage classes. The two voltage classes are 24 VDC Negative Ground and 110 or 240 VAC 50-60 Hz with connected electrical or earth ground. High voltage (110 or 240 VAC) wiring must enter through bottom conduit. Low voltage and signaling wires must enter through top conduit and remain separated per NFPA 70, NEC, and local codes.

- 4. If the thermal circuit breaker has tripped (opened circuit), the 110 or 240 VAC 50-60 Hz power will still be energized up to the primary side of the thermal breaker. For safety, disconnect supply power of conductors to three power circuits in the enclosure.
- To clean 24 VDC negative ground fan with electronic compressed air container, disconnect all power. Note: the 24 VDC negative ground fan will not operate if positive and negative conductors are connected on the wrong terminals.
- 6. To minimize and summer time heat build up in enclosure, install a dark color sun shield with sides to provide shade for the enclosure. At the inclined face above the enclosure at the point of contact with the building structure leave at least 1/2" or (1.25 cm) space. This will generate heat and cause an upward airflow and help maintain the enclosure temperature approximately the same as ambient air temperature.
- 7. The 110 or 240 VAC single phase 50-60 Hz heater does not require standby or secondary power because the enclosure environment is supervised by a latching supervisory circuit in the alarm control unit or panel.
- 8. Replacement of heater assembly and gasket is required five years from installation date. Contact STI to order replacement Heater Kit STI-HK3.
- 9. All field wiring within this enclosure must be rated for a minimum operating range of 0°C 110°C.

Schematic Diagrams





Polycarbonate Cleaning Instructions

Rinse with water to remove abrasive dust and dirt. Wash with soap or mild detergent, using a soft cloth. Rinse once more, then dry with a soft cloth or chamois. Exercise caution when using water inside enclosure. Make sure unit is completely dry inside before reassembling. Do not use razor blades.

Specifications

Internal Dimensions

PART #	HEIGHT	WIDTH	DEPTH
1200A-HTR	6.25 in.	4.125 in.	1.25 in.
1200A-HTR240	(158mm)	(104mm)	(31mm)

Polycarbonate Enclosure

Flammability	UL94 V-2
Wall Thickness	back box: .20 inches (5.1mm) cover: .12 inches (3.1mm)
NEMA Rating	3R
Warranty Lifetime against breakage in normal use.	

Silicone Laminate Heater

STI-1200A-HTR 110 VAC 50/60 Hz	UL Recognized Component
STI-1200-A-HTR240 240 VAC 50/60 Hz	UL Recognized Component
100 Watts	
Life: @-10°C (14°F) ~ 70°C (158°F)	5 Years
Duty Cycle: -40°F (-40°C)	16%
-79°F (-57°C)	38%
-99°F (-73°C)	100%

Fan


24 VDC (±10%), 90 mA	UL Recognized Component
Life	5 Years Continuous Duty
WARNING: The polarity of the circulating fan is important as it only rotates in one	

direction with red lead being positive.

MISE EN GARDE: La polarité du ventilateur de circulation est importante car il ne tourne que dans un sens avec son fil rouge étant celui du pôle positif.

Gasket


Material	Neoprene
Life	5 Years



Installation Instructions

Mount Enclosure back box - Refer to Fig 1

- Set heater assembly with cover aside. Press (4) plastic tabs into slots on back box and drill (4) 1/4" (6.4mm) diameter holes in mounting surface for plastic anchors provided. Attach back box to wall using (4) #10 x 1-1/2"screws provided.
- 2. Attach 3/4" rigid conduit and conduit sealing hub (Crouse-Hinds 3/4" EYSX 21 or equivalent) to back box. Conduit should be installed according to applicable NEC and local codes.




3. Pull 24 VDC and alarm wiring into back box through top conduit; and pull 110 or 240 VAC wiring into back box through bottom conduit per NFPA 70, NEC and local codes.

Note: Wire size to be 12-22 AWG.

Install Fire Alarm Pull Station and Dual Monitor Module to Heater and Cover Assembly - Refer to Fig 2.

- 4. Lift the cover from heater assembly and allow it to hang from cables. Connect the provided high temperature wires to the pull station.
- 5. Attach the pull station to the slide plate using (2) #6-32 x 3/8" screws provided. Adjust the slide plate so the pull station or slide plate does not cover either the fan opening or vent slots. Note: If the fan opening or vent slots are covered, the plate mounting screws can be moved to the alternate mounting position. After mounting pull station adjust the slide plate so there are no gaps large enough to touch
- the heaters behind the pull station.
 Turn assembly over and mount dual monitor module to the backside of the heater assembly using (4) #6-32 x 1" screws and (4) 3/8" standoffs provided. Replace cover.



Wiring

- 7. Wire one channel of the dual monitor module to the low temp warning terminals (pins 1 & 2) on the 24 VDC terminal block. Wire the other channel to the fire alarm terminals (pins 5 & 6) on the same terminal block. Add any end of the line devices as required for the alarm system.
- 8. Connect wires from alarm panel to the dual monitor module according to design specifications. Connect continuous 24 VDC supply to fan power terminals (pins 3 & 4) of the 24 VDC terminal block.

Note:

- 1. Fan is polarity sensitive and must be connected correctly for fan to operate.
- 2. Fan operates continuously.
- 9. Connect the 110 or 240 VAC supply to the high voltage terminal block pins 4, 5, and 6. Earth Ground, AC Low, and AC High respectively.
- 10. Attach the heater and cover assembly to the back box with (4) #8-32 x 3/4" socket cap screws and (4) #8 flat washers.
- 11. Record installation date in space provided on the label located on underside of cover. Unit is ready for testing. 12. Turn all power to "ON" position.

Note: Fan runs continuously. This system requires three sources of power:

- 1. 110 or 240 VAC heater on the load side of the fuse holder.
- 2. 24 VDC power source for the circulating fan. Check fan to see if operating; if not check polarity and reverse, then try again.
- 3. Fire alarm initiating circuit and temperature warning monitor.